



CABLE ROUTING

- ① Clutch cable
- ② Parking brake cable
- ③ Front brake cable
- ④ Throttle switch lead
- ⑤ Throttle cable
- ⑥ Band
- ⑦ Handlebar switch lead (Left)
- ⑧ Voltage regulator lead
- ⑨ Main switch lead
- ⑩ Wire harness
- ⑪ Ground lead

- A For installation of the clutch cable through the guide, route the clutch cable on the left side of the front brake cable.
- B The parking brake cable should be routed behind the front brake cable, and on the right side of the guide.
- C The throttle cable should be routed through the guide behind the clutch cable.
- D Leads should be routed behind the cables.
- E The ground and voltage regulator leads should be routed in front of the cables.

